

MPS - PILOT SEAT

Instruction Manual
Bedienungsanleitung
Mode d'emploi


PARTS

[dimensions in mm / different scales]
No extra or spare parts listed!


1x




1x




1x



4x




4x




8x




4x



8x




8x




PARTS FOR OPTIONAL ARM-RESTS

1x




Already positioned in the appropriate threads under the seat (unscrew first)


8x



8x








8x



PARTS FOR THE OPTIONAL JOYSTICK CUTOUT DELETE INSERT


[dimensions in mm / different scales]
No extra or spare parts listed!




ASSEMBLY




It is not recommended to use power tools.
Please make sure the screws are running smoothly in the threads.
If not readjust the screw.
Do not use too much downward pressure.







arm-rests
optional





4x slot nut M8


For mounting on
MTX platform have a
look at page 14.




To get access to the
mounting holes pull
lever and move the
parts of the slider.









4x slot
nut M8







2x M8x14
OR
2x M8x12

bottom view



Mounting on MTX platform



ASSEMBLY OF THE OPTIONAL JOYSTICK CUTOUT DELETE INSERT

