














MTS TV/MONITOR INTERNAL

Instruction Manual
Bedienungsanleitung
Mode d'emploi

PARTS



[dimensions in mm / different scales]
No extra or spare parts listed!




Screws for TV assembly / VESA

Consult your TV's manual regarding the maximum screw-in depth!

We include these screws but accept no responsibility if they are incompatible with your TV!




ASSEMBLY




8x
pre-assembled
universal connector

475 mm

600 mm





Slot nuts on the inside must be rotated 180° so that they do not collide.





Adjust the height for your display as desired and the distance between the profiles suitable for your TV's VESA.



Distance between the profiles				
VESA	100	200	300	400
Distance	60	160	260	360















Distance between the brackets				
VESA	100	200	300	400
Distance	61	161	261	361



Consult your TV's manual regarding the maximum screw-in depth!

Loosely screw the screws into the upper VESA threads of your TV.

We include screws but accept no responsibility if they are incompatible with your TV!

