











MTS WINWING MIP


Instruction Manual
Bedienungsanleitung
Mode d'emploi

PARTS


[dimensions in mm / different scales]
No extra or spare parts listed!




1x




1x




4x



9x




2x




BAG 1 (Front Frame)


4x




4x








20x







20x




BAG 2



BAG 3 (Winwing MIP assembly)




PRE-ASSEMBLED




with this parts:


2x




4x




8x




4x




4x




4x





4x





ASSEMBLY















3x





1x










The inclination of the profile can be adjusted by loosening the screw marked in red.





USUALLY PRE-ASSEMBLED


2x







ASSEMBLY OF THE FRONT FRAME








for both sides











Detail view





OPERATION

Loosen the
red marked
bolts on each
side to adjust
the height.

