






Instruction Manual Bedienungsanleitung Mode d'emploi


#### PARTS


[dimensions in mm / different scales] No extra or spare parts listed!

































#### BAG 1
















BAG 3 with parts for yoke assembly












4x


4x





# ASSEMBLY




































flat head, black










## ASSEMBLING A BRUNNER YOKE






## UNIVERSAL ASSEMBLING WITH BRACKETS





Alternative positions for the brackets



# OPERATION

